

The Formwork Experts.

Platforms assembled from system components

with Universal suspension head

User Information

Instructions for assembly and use (Method statement)



Contents

3	Introduction
3	Elementary safety warnings
6	Services
7	Ducduct docovertice
1	Product description
8	Areas of use
9	Structural design
11	Anchoring on the structure
11	Positioning point and suspension point
20	Other possible anchorages
21 _	Assembly
21	Assembling platform
21	
26	Repositioning
26	Moving the platform
28	Transport fork 1.3t adjustable
20	Starting un
29	
29	Hanging the platform into place
30	Dismantling
31	General
31	Design variants
33	Suspension head WS10
35	Sideguards on exposed platform-ends
36	Fall-arrest systems on the structure
37	Transporting, stacking and storing
41	Article list

Introduction

Elementary safety warnings

User target groups

- This booklet is aimed at all persons who will be working with the Doka product or system that it describes. It contains information on the standard design for setting up this system, and on correct, compliant utilisation of the system.
- All persons working with the product described herein must be familiar with the contents of this booklet and with all the safety instructions it contains.
- Persons who are incapable of reading and understanding this booklet, or who can do so only with difficulty, must be instructed and trained by the customer.
- The customer is to ensure that the information materials provided by Doka (e.g. User Information booklets, Instructions for Assembly and Use, Operating Instruction manuals, plans etc.) are up to date and available to all users, and that they have been made aware of them and have easy access to them at the usage location.
- In the relevant technical documentation and formwork utilisation plans, Doka shows the workplace safety precautions that are necessary in order to use the Doka products safely in the usage situations shown.

In all cases, users are obliged to ensure compliance with national laws, standards and regulations throughout the entire project and to take appropriate additional or alternative workplace safety precautions where necessary.

Hazard assessment

The customer is responsible for drawing up, documenting, implementing and continually updating a hazard assessment at every job-site.
 This booklet serves as the basis for the site-specific hazard assessment, and for the instructions given to

hazard assessment, and for the instructions given to users on how to prepare and utilise the system. It does not substitute for these, however.

Remarks on this booklet

- This document can be used as general Instructions for Assembly and Use (Method Statement) or be incorporated into site-specific Instructions for Assembly and Use (Method Statement).
- The graphics, animations and videos in this document or app sometimes depict partially assembled assemblies and may require additional safety equipment and/or measures to comply with safety regulations.

The customer must ensure all applicable regulations are complied with, even if they are not shown or implied in the graphics, animations and videos provided.

 Individual sections contain further safety instructions and/or special warnings as applicable.

Planning

- Provide safe workplaces for those using the formwork (e.g. for when it is being erected/dismantled, modified or repositioned etc). It must be possible to get to and from these workplaces via safe access routes!
- If you are considering any deviation from the details and instructions given in this booklet, or any application which goes beyond those described in the booklet, then revised static calculations must be produced for checking, as well as supplementary assembly instructions.

Regulations; industrial safety

- All laws, Standards, industrial safety regulations and other safety rules applying to the utilisation of our products in the country and/or region in which you are operating must be observed at all times.
- If a person or object falls against, or into, the sideguard component and/or any of its accessories, the component affected may only continue in use after it has been inspected and passed by an expert.

Rules applying during all phases of the assignment

- The customer must ensure that this product is erected and dismantled, reset and generally used for its intended purpose in accordance with the applicable laws, standards and rules, under the direction and supervision of suitably skilled persons.
 These persons' mental and physical capacity must not in any way be impaired by alcohol, medicines or drugs.
- Doka products are technical working appliances which are intended for industrial / commercial use only, always in accordance with the respective Doka User Information booklets or other technical documentation authored by Doka.
- The stability and load-bearing capacity of all components and units must be ensured during all phases of the construction work!
- Do not step on or apply strain to cantilevers, closures, etc. until suitable measures to ensure their stability have been correctly implemented (e.g. by tie-backs).
- Strict attention to and compliance with the functional instructions, safety instructions and load specifications are required. Non-compliance can cause accidents and severe injury (risk of fatality) and considerable damage to property.
- Sources of fire in the vicinity of the formwork are prohibited. Heaters are permissible only when used correctly and situated a correspondingly safe distance from the formwork.
- Customer must give due consideration to any and all effects of the weather on the equipment and regards both its use and storage (e.g. slippery surfaces, risk of slipping, effects of the wind, etc.) and implement appropriate precautionary measures to secure the equipment and surrounding areas and to protect workers.
- All connections must be checked at regular intervals to ensure that they are secure and in full working order.

In particular threaded connections and wedged connections have to be checked and retightened as necessary in accordance with activity on the jobsite and especially after out-of-the-ordinary occurrences (e.g. after a storm).

 It is strictly forbidden to weld Doka products – in particular anchoring/tying components, suspension components, connector components and castings etc. – or otherwise subject them to heating.

Welding causes serious change in the microstructure of the materials from which these components are made. This leads to a dramatic drop in the failure load, representing a very great risk to safety.

It is permissible to cut individual tie rods to length with metal cutting discs (introduction of heat at the end of the rod only), but it is important to ensure that flying sparks do not heat and thus damage other tie rods.

The only articles which are allowed to be welded are those for which the Doka literature expressly points out that welding is permitted.

Assembly

- The equipment/system must be inspected by the customer before use, to ensure that it is in an acceptable condition. Steps must be taken to exclude components that are damaged, deformed, or weakened due to wear, corrosion or rot (e.g. fungal decay).
- Using our safety and formwork systems together with those of other manufacturers can create risks that may lead to injury and damage to property. This requires separate verification by the user.
- The equipment/system must be assembled and erected in accordance with the applicable laws, standards and rules by trained customer personnel whilst maintaining any applicable safety inspections that may be required.
- It is not permitted to modify Doka products; such modifications constitute a safety risk.

Closing the formwork

 Doka products and systems must be set up so that all loads acting upon them are safely transferred!

Pouring

 Do not exceed the permitted fresh-concrete pressures. Over-high pouring rates overload the formwork, cause greater deflection and risk breakage.

Stripping the formwork

- Do not strip out the formwork until the concrete has reached sufficient strength and the person in charge has given the order for the formwork to be stripped out!
- When stripping out the formwork, never use the crane to break concrete cohesion. Use suitable tools such as timber wedges, special pry-bars or system features such as Framax stripping corners.
- When stripping out the formwork, do not endanger the stability of any part of the structure, or of any scaffolding, platforms or formwork that is still in place!

Transporting, stacking and storing

 Observe all country-specific regulations applying to the handling of formwork and scaffolding. For system formwork the Doka slinging means stated in this booklet must be used – this is a mandatory requirement.

If the type of sling is not specified in this document, the customer must use slinging means that are suitable for the application envisaged and that comply with the regulations.

- When lifting, always make sure that the unit to be lifted and its individual parts can absorb the forces that occur.
- Remove loose parts or secure them so that they cannot slip out of position and drop.
- When lifting formwork or formwork accessories with a crane, no persons must be carried along, e.g. on working platforms or in multi-trip packaging.
- All components must be stored safely, following all the special Doka instructions given in the relevant sections of this document!

Maintenance

 Only original Doka components may be used as spare parts. Repairs may only be carried out by the manufacturer or authorised facilities.

Miscellaneous

The weights as stated are averages for new material; actual weights can differ, depending on material tolerances. Dirt accretions, moisture saturation, etc. can also affect weight.

We reserve the right to make alterations in the interests of technical progress.

Eurocodes at Doka

The permissible values stated in Doka documents (e.g. $F_{perm} = 70 \text{ kN}$) are not design values (e.g. $F_{Rd} = 105 \text{ kN}$)!

- It is essential to avoid confusing permissible values with design values!
- Doka documents will continue to state the permissible values.

Allowance has been made for the following partial factors:

γ_F = 1.5

- γ_{M, timber} = 1.3
- γ_{M, steel} = 1.1
- k_{mod} = 0.9

Consequently, all the design values for an EC design calculation can be determined from the permissible values.

Symbols used

The following symbols are used in this document:



This is a notifier drawing attention to an extremely dangerous situation in which noncompliance with this notifier will lead to death or severe, irreversible injury.

WARNING

DANGER

This is a notifier drawing attention to a dangerous situation in which non-compliance with this notifier can lead to death or severe, irreversible injury.



CAUTION

This is a notifier drawing attention to a dangerous situation in which non-compliance with this notifier can lead to slight, reversible injury.



NOTICE

This is a notifier drawing attention to a situation in which non-compliance with this notifier can lead to malfunctions or damage to property.



Instruction

Indicates that actions have to be performed by the user.



Sight-check

Indicates that you need to do a sight-check to make sure that necessary actions have been carried out.



Tip

Points out useful practical tips.



Reference

Cross-references other documents.

Services

Support in every stage of the project

- Project success assured by products and services from a single source.
- Competent support from planning through to assembly directly on site.

Project assistance from start to finish

Every single project is unique and calls for individualised solutions. When it comes to the forming operations, the Doka team can help you with its consulting, planning and ancillary services in the field, enabling you to carry out your project effectively, safely and reliably. Doka assists you with individual consulting services and customised training courses.

Efficient planning for a safe project sequence

Efficient formwork solutions can only be developed economically if there is an understanding of project requirements and construction processes. This understanding is the basis of Doka engineering services.

Optimise construction workflows with Doka

Doka offers special tools that help you in designing transparent processes. This is the way to speed up pouring processes, optimise inventories and create more efficient formwork planning processes.

Custom formwork and on-site assembly

To complement its system formwork range, Doka offers customised formwork units. And specially trained personnel assemble load-bearing towers and formwork on site.

Just-in-time availability

Formwork availability is a crucial factor in realising your project on time and on budget. The worldwide logistics network puts the necessary formwork quantities on site at the agreed time.

Rental and reconditioning service

The formwork material needed for any particular project can be rented from Doka's high-performing rental park. Doka Reconditioning cleans and overhauls both client-owned equipment and Doka rental equipment.



upbeat construction

digital services for higher productivity

From planning through to completion - with upbeat construction we'll be moving construction forward and upping the beat for more productive building with all our digital services. Our digital portfolio covers the entire construction process and is being extended all the time. To find out more about our specially developed solutions go to <u>doka.com/upbeatconstruction</u>.

High performance, in all stages of the project

Product description

Platforms assembled from system components with Universal suspension head

Easy to use and versatile. With the Universal suspension head and the Doka system components, platforms can be perfectly adapted to widely differing project requirements. The area of application of the Universal suspension head extends from applications in simple storage and working platforms, pouring platforms and bridge edge beam brackets for vertical walls to customer applications for inclined structures or narrow shafts.

Features of the Universal suspension head

- High load-bearing capacity for economical solutions with widely spaced brackets and high live loads
- Integral combination safety and crane-slinging bow for protection against unintentional lift-out and as defined slinging point for slinging to crane
- Possibility of directly pinning the Doka waling systems in different fixing positions enables project-specific platforms to be assembled without special parts
- Optional safety wedge for secure suspension even on structures inclined at angles >45 °

Product presentation

System dimensions



a ... 107 mm (Multi-purpose waling WS10 and Multi-purpose waling WU12)

- b ... 150 mm (Top100 tec waling WU14)
- c ... 125 mm (Pair of Channels UK12)
- d ... Diam. 20,5 mm
- e ... 140 mm
- f ... 50.5 mm
- g ... 333 mm h ... 365 mm
- n ... 365 mm
- A Safety bow

Usable waling systems





Follow the directions in the 'Large-area formwork Top 50', 'Large-area formwork Top 100 tec' and 'Doka UniKit' User Information booklets!

Areas of use

Straight walls



a ... 277 mm

b ... 170 mm

A Universal suspension head

B Multi-purpose waling

- $\boldsymbol{\mathsf{C}} \ \ \mathsf{Bracing}$
- D Strut or spindle strut
- E Insertion adapter XP
- F Handrail post XP 1.20m
- **G** Beam support WS10-WU16
- H Railing adapter XP DokaCC
- I Squared timber

Structural design

Structural design of the Universal suspension head

Imposed loads



- A Cone screw M30 SW50 7cm
- B Universal climbing cone 15.0 2G
- C Stop anchor 15.0 (lost anchoring component)

Imposed loads with Universal climbing cone 15.0 2G

- and Cone screw M30 SW50 7cm
- H ... permitted horizontal load: 60 kN
- V ... permitted vertical load: 50 kN

Note the restrictions in the sections headed 'Permissible load combination of V and H' and 'Other possible anchorages'!

NOTICE

When making project-specific platforms, observe the following points:

- Position brackets as symmetrically as possible and keep their cantilever short.
- Ensure that all loads are applied centrally.
- The stability of the platforms must be ensured during all phases of the construction work!

Risk of platforms tipping over when **loads are** applied eccentrically.

If it is unavoidable to extend a cantilever to one side, observe the following points:

- Choose the widest possible bracket spacing in relation to the cantilever!
- Allow for the greater influence on the bracket in the cantilevering region!
- Contact your Doka technician for information on further measures to prevent platforms tipping over.

The anti-liftout guards are not suitable for sustaining planned forces! The anti-liftout guard is only designed to prevent the platform from being accidentally lifted out of its suspension point while work is in progress.

Permissible load combination of V and H

Multi-purpose waling WS10 and WU12



Connection plates on the vertical waling must always face toward the wall.

Multi-purpose walings WU14 and pairs of Channels UK12



 $^{1)}$ Connection plates on the vertical waling must always face toward the wall.

WARNING

The Universal suspension head must be pinned to at least one waling (vertical or horizontal waling) with 2 Connecting pins 10cm and the connecting pins must be secured with 2 spring cotters.



Structural design of railings

Max. influence width per handrail post

Guardrail boards 2.4 x 15 cm Guardrail boards 3 x 15 cm Guardrail boards 4 x 15 cm Scaffold tubes 48.3mm Protective gratin 2.70x1.20 and 2.70x0.60	ings XP)m 60m
Dynamic pressure d _a	-©-
0.2 kN/m ² 1.9 m 2.7 m 3.6 m 5.0 m	
0.6 kN/m ² 1.9 m 2.7 m 2.7 m 5.0 m 2.5 m	
1.1 kN/m² 1.5 m 1.5 m 2.8 m	
1.3 kN/m² 1.2 m 1.2 m 2.4 m	

A Insertion adapter XP

B Toeboard holder XP 1.20m

C Handrail post XP 1.80m or

Handrail post XP 1.20m + Handrail post XP 0.60m

E Connecting pin 10cm + Spring cotter 5mm

	Handrail po	ost T 1.80m	Universal railing SK 2.00m				Multi-purpose waling WS 10 with Corner con- necting plate SK
	Guardra	ail board	Scaffold tube	Guardra	ail board	Full enclosure	Full enclosure
Dynamic pressure q _(ze)		98654-230-01		B · · · · · · · · · · · · · · · · · · ·	98054-233-01		
	Height of gua	rdrail boards:		Height of gua	rdrail boards:		÷
	≤15 cm	≤20 cm		≤15 cm	≤20 cm		
≤ 1.1 kN/m ²	1.83 m	1.33 m	5.0 m	3.5 m	3.1 m	1.3 m	3.5 m
≤ 1.3 kN/m ²	1.55 m	1.13 m	5.0 m	3.4 m	2.6 m	1.1 m	3.0 m
≤ 1.7 kN/m ²	1.18 m	0.86 m	5.0 m	2.6 m	2.0 m	0.8 m	2.3 m
A Handrail nost T 1 80m							

A Handrail post T 1.80m

B Universal railing SK 2.00m

C Multi-purpose waling WS10 Top50 2.25m

D Corner connecting plate SK

E Connecting pin 10cm + Spring cotter 5mm

Anchoring on the structure

Positioning point and suspension point



- A Universal climbing cone or Universal climbing cone 15.0 2G
- B Sealing sleeve K 15.0 (lost anchoring component)
- **C** Stop anchor (lost anchoring component)
- D Cone screw M30 SW50 7cm
- Universal climbing cone 15.0 or Universal climbing cone 15.0 2G
 - The positioning point and the suspension point are both prepared using this one single type of cone
- Stop anchor 15.0
 - Lost anchoring component for anchoring the universal climbing cone (and thus the working platform) in the concrete from one side.
- Cone screw M30 SW50 7cm
 - Positioning point for fastening the universal climbing cone.
 - Suspension point safe means of suspending the working platform.

NOTICE

!

- Use the Cone screw M30 SW50 7cm (head of screw is green) for the positioning point and the suspension point!
- The use of residual stocks of the Cone screw B 7cm (head of screw is red) can continue until the end of 2023.

Universal climbing cones 15.0

Universal climbing cone 15.0 2G	Universal climbing cone 15.0
9710-381-01	9710-381-02

-

- Advantages of the Universal climbing cone 15.0 **2G**:
- Orange mark on the end face for easy identification
- Clear view of the code on the end face with stop anchor installed



- A Orange mark on end face
- **B** Code on the stop anchor

Sealing sleeve K 15.0





- C Sealing sleeve K 15.0 (orange)
- D Tab on the sealing sleeve



The tab on the sealing sleeve sits against the thread of the universal climbing cone and prevents the stop anchor from working loose.

Types of stop anchor



A Mark for screw-in depth

B Code for stop-anchor type



The stop anchor has an identification code on the end face.

- The code is a combination of a letter and a number and it unequivocally describes the features of the stop anchor:
 - Letter: Tie-rod size and size of the stopanchor plate.
 - Number: Length of the stop anchor in cm
- Easy identification of the stop-anchor type before and after the concrete has been poured

Stop anchor 15.0 A16 and A21



^	Stop anchor 15.0
A	a size of stop-anchor plate: 55 mm
16	b tie-rod length: 16.0 cm

c ... installation depth: 21.5 cm

d ... minimum wall thickness: 23.5 cm (where the concrete cover is 2 cm)

d ... minimum wall thickness: 24.5 cm (where the concrete cover is 3 cm)

e ... concrete cover

•	Stop anchor 15.0			
~	a size of stop-anchor plate: 55 mm			
21	b tie-rod length: 21.0 cm			

c ... installation depth: 26.5 cm

d ... minimum wall thickness: 28.5 cm (where the concrete cover is 2 cm)

d ... minimum wall thickness: 29.5 cm (where the concrete cover is

3 cm) e ... concrete cover

Stop anchor 15.0 B11





B	Stop anchor 15.0
Б	a Size of stop-anchor plate: 90 mm
11	b Tie-rod length: 11.5 cm

c ... Installation depth: 17 cm

d ... Minimum wall thickness: 19 cm (where the concrete cover is 2 cm)

d ... Minimum wall thickness: 20 cm (where the concrete cover is 3 cm)

e ... concrete cover



WARNING

- The short **Stop anchor 15.0 B11** has a much lower load-bearing capacity than the Stop anchor 15.0 A16.
 - The short stop anchor may only be used on systems with low tensile loads at the anchoring location, such as on climbing systems inside shafts.
 - If the geometry will only allow installation of short stop anchors, then revised static calculations and/or extra reinforcement steel may be required where any higher tensile loads are expected.
 - The Stop anchor 15.0 B11 is only permitted for wall thicknesses < 24 cm. For wall thicknesses ≥ 24 cm, the Stop anchor 15.0 A16 (or larger) must be used.

Preparing the positioning point

WARNING

Sensitive anchoring, suspension and connector components!

- > Never weld or heat these components.
- Any components that are damaged or weakened by corrosion or wear must be withdrawn from use and destroyed.





9710-383-19



Preparing the positioning point

- Push the sealing sleeve all the way onto the universal climbing cone.
 - The coloured mark on the universal climbing cone and the colour of the sealing sleeve must be the same.



- A Universal climbing cone 15.0 2G
- **B** Sealing sleeve K 15.0 (orange)
- **C** Orange mark on end face

For Universal climbing cones 15.0 (without coloured mark), the diameter of the form-tie hole must be 15 mm.

a		r
	97	10-386-0

a ... diam. 15 mm

Note:

Do not screw the stop anchor in until the sealing sleeve is pushed fully on to the universal climbing cone.

WARNING

Always screw the stop anchor into the universal climbing cone until it fully engages (up to the depth mark).

Not screwing the stop anchor fully into the cone may lead to reduced load-bearing capacity and failure of the suspension point – resulting in possible injury and/or damage.



b ... 0 mm

- c ... 15 mm
- **D** Stop anchor 15.0 (expendable anchoring component)
- E Depth mark
 - The depth mark on the stop anchor must be right up against the universal climbing cone = must be screwed in to the full depth.



- b ... > 0 mm not permitted
- The sealing sleeve must be completely pushed onto the Universal climbing cone.



c ... > 15 mm not permitted

Positioning point with Cone screw M30 SW50 7cm (with hole drilled through form-ply)

Installation:

- Fasten a packing plate (e.g. Dokaplex 15 mm) to the form-ply (position as shown in shop drawing / assembly drawing).
- Drill a diam. 30 mm hole in the form-ply (position as shown in shop drawing / assembly drawing).
- Secure the prepared positioning point to the form-ply with Cone screw M30 SW50 7cm.



- a ... 35 45 mm
- A Universal climbing cone 15.0 2G
- B Stop anchor 15.0
- C Cone screw M30 SW50 7cm
- D Packing plate



The Form-ply protector 32mm protects the form-ply from damage around the positioning point. This is a particular advantage for formwork with high numbers of repeat uses.

Possible thicknesses of form-ply: 18 - 27 mm In order to fit the form-ply protector, a 46 mm diam. hole must be drilled in the form-ply first.



E Form-ply protector 32mm (width across flats 70 mm)

Where necessary, the Form-ply protector 32mm can be closed off with a Cover cap D35x3 (included with product).



Positioning point with Positioning clamp M30 (with hole drilled through form-ply)

Because the hole is drilled with a diameter of only 9 - 10 mm, the positioning point can be relocated at smaller intervals than would be possible with the Cone screw M30 SW50 7cm.



- A Universal climbing cone 15.0 2G
- B Stop anchor 15.0
- F Socket connector M30 of the Positioning clamp M30
- $\textbf{G} \hspace{0.1 cm} \text{M8 wing bolt of the Positioning clamp M30}$

Installation:

Drill a diam. 9 - 10 mm hole in the form-ply (position as shown in shop drawing / assembly drawing).

Nail the M8 wing bolt onto the form-ply to make it easier to mount the cone.

Shortened double-headed nails make it easier to remove the wing bolt.



- Screw a Socket connector M30 all the way into the universal climbing cone and tighten it.
- Screw the prepared positioning point onto the M8 wing bolt (make sure that it seals against the formwork).

Positioning point with Positioning disk M30 (with no hole drilled through form-ply)

For special applications only, when it is not possible to drill through the form-ply (e.g. where there are Doka beams or formwork panel frame profiles directly behind the positioning point).



- A Universal climbing cone 15.0 2G
- B Stop anchor 15.0
- H Positioning disc M30



NOTICE

It is not permitted to use the Positioning disc M30 more than once in the same position, as it cannot be fixed firmly and securely in the old nail-holes.



Tightness of the contact surface between the positioning disc and the climbing cone can be further increased by applying a thin film of water-resistant grease.

Installation:

- Fix the Positioning disc M30 to the form-ply using 2.8x60 nails (position as shown in shop drawing / assembly drawing).
- Screw the prepared positioning point onto the Positioning disc M30 and tighten it.

User Information Platforms assembled from system components

The universal climbing cone must be

embedded so that it is flush with the con-

Check of the positioning point

- Before pouring, check all positioning points and suspension points again.
 - The sealing sleeve must be completely pushed onto the Universal climbing cone.
 - The depth mark on the stop anchor must be right up against the universal climbing cone = must be screwed in to the full depth.
 - Tolerance for locating the positioning points and suspension points: ±10 mm in the horizontal and the vertical.



- b ... 15 mm
- The axis of the universal climbing cone must be at right-angles to the surface of the concrete – maximum angle of deviation: 2°.



crete surface.



c ... > 0 mm not permitted

Pouring



Mark the positions of the anchoring points at the top edge of the formwork to make them easier to locate when the concrete is being poured.

> Prevent the vibrator from touching the stop anchors.

Do not place concrete from directly above the stop anchors.

These measures prevent the anchors from working loose during pouring and vibration.

Stripping the formwork

Remove the connecting parts holding the positioning point to the formwork either before or after stripping, depending on which connecting parts are used.

Positioning point with Cone screw M30 SW50 7cm:

Remove the Cone screw M30 SW50 7cm before stripping.



- A Cone screw M30 SW50 7cm
- B Box nut 50 3/4"
- C Extension 20cm 3/4"
- D Reversible ratchet 3/4"

Positioning point with Positioning clamp M30:

- Remove the M8 wing bolt before stripping.
- > Remove the Socket connector M30 after stripping.



- F Reversible ratchet 1/2"
- G Extension 11cm 1/2"
- I Socket connector M30 of the Positioning clamp M30

Positioning point with Positioning disc M30:

Remove the Positioning disc M30 after stripping.



- E Positioning disc M30
- F Reversible ratchet 1/2
- G Extension 11cm 1/2"
- H Hexagon bit socket 14mm 1/2"

Preparing the suspension point

Check of the suspension point

NOTICE

ļ

- Stop anchor type and climbing cone must be as specified in the assembly drawing or shop drawing, as applicable.
- Check the coloured mark on the Universal climbing cone and the code on the stop anchor.



- A Orange coloured mark
- (only on Universal climbing cone 15.0 2G)
- B Code on the stop anchor

> Check the placement depth of the stop anchor.



The Safety Ruler SK permits a quick check to ensure that placement depth is within the permissible range.



a ... perm. placement depth: 55 - 65 mm

C Safety Ruler SK

Dimensioning the suspension point

The required cube compressive strength of the concrete at the time of loading must be specified separately for each project by the structural designer. It will depend on the following factors:

- Ioad actually occurring
- Iength of the stop anchor
- reinforcement / extra reinforcement steel
- distance from edge

The introduction of the forces, the transfer of these forces into the structure, and the stability of the overall construction, must all be verified by the structural designer.

The required cube compressive strength fck,cube,current must be at least 10 N/mm², however.

i

Follow the directions in the Calculation Guide entitled 'Load-bearing capacity of anchorages in concrete' or ask your Doka technician!

Hanging the platform into place

WARNING

► Use only the Cone screw M30 SW50 7cm for the positioning point and suspension point (head of screw is green)!

Screw the Cone screw M30 SW50 7cm into the universal climbing cone until it engages, and tighten it firmly.

A tightening torque of 100 Nm (20 kg, assuming a ratchet-length of approx. 50 cm) is sufficient.



Ensure that control dimension b = 28 -32 mm!



A Universal climbing cone 15.0 2G

C Cone screw M30 SW50 7cm



WARNING

Overtightening (> 100 Nm) can cause damage to or even breakage of the anchor!

> The Reversible ratchet 3/4" must be used for screwing in and fixing the Cone screw M30 SW50 7cm into the universal climbing cone.

Reversible ratchet 3/4"	Reversible ratchet 3/4" with extension	Ratchet MF 3/4" SW50
EFT Tr687-200-01	CT687-200-01	С тг687-200-01

Hang the platform into place.



Once the platform has been hung into place on the suspension cone, the load is removed from the 4part lifting chain.



The red safety bows drop to their initial position, automatically securing the platform against lift-out.

Secured position = safety bow (red) fully lowered in the Universal suspension head.

Dismounting the suspension point

- Remove the Cone screw M30 SW50 7cm.
- Remove the universal climbing cone.



- A Universal climbing cone 15.0 2G
- B Universal cone spanner 15.0/20.0
- C Extension 20cm 3/4"
- D Reversible ratchet 3/4"

Sealing the suspension point

Grout level with the rest of the surface

Sealing of the suspension points can be a requirement, for reasons of rust prevention.

 Fill the cavity of the suspension point with mortar and grout it smoothly.

Fair-faced concrete plug 52mm plastic

Push the fair-faced concrete plug into the hole of the suspension point.



- E Sealing sleeve
- F Fair-faced concrete plug 52mm plastic

Concrete cone 52mm

- Remove the sealing sleeve.
- Glue the concrete cone into the hole of the suspension point.



G Concrete cone 52mm

The concrete plug is glued into place with standard concrete adhesive.

Other possible anchorages

Load-bearing capacity of the steel of suitable suspension points

	Vperm. [kN]	H _{perm.} [kN]	
Universal climbing cone 15.0 2G + Cone screw M30 SW50 7cm	50	60	
Suspension cone 15.0 5cm	50	60	
Suspension cone 15.0 f. insulation up to 11cm + Cone screw Rd28	20	55	
Screw-in cone 15.0 + Bridge edge beam anchor 15.0	30	30	
Suspension cone 15.0 with collar	50	55	
The required cube compressive strength of the con- crete at the time of loading must be specified sepa- rately for each project by the structural designer . It will depend on the following factors:		Follow the entitled 'Lo n concrete	directions in the Calculation Guide ad-bearing capacity of anchorages ', and/or ask your Doka technician!
 load actually occurring anchoring depth h_{ef} reinforcement / extra reinforcement steel distance from edge The introduction of the forces, the transfer of these forces into the structure, and the stability of the overall construction, must all be verified by the structural designer 		NOTICE Separate s dimensioni	tatics analysis is required for ng of the suspension point.
The required cube compressive strength f _{ck,cube,current} must be at least 10 N/mm ² , however.			

Anchorage with Suspension cone 15.0 5cm

Lost parts	Reusable parts				
Pigtail anchor 15.0	Sealing sleeve 15.0 5cm	Cantilever posi- tioning cone 15.0 5cm	Tie rod 15.0, length approx. 20 cm	Super plate 15.0	Suspension cone 15.0 5cm
			(1011)		
or	or		c	br	
Stop anchor 15.0	Sealing sleeve S 15.0 5cm		Fixing p	late 15.0	
annunun			O		

Suspension cone 15.0 f. insulation up to 11cm

Lost pa	arts	Reusable parts		
Pigtail anchor 15.0Sealing sleeve 15.0 f. insulation up to 11cm		Suspension cone 15.0 f. insulation up to 11cm	Cone screw Rd28	
or Stop anchor 15.0		in addition, where needed: Positioning disc Rd28		
annananan				

Anchorage with Screw-in cone 15.0

Lost parts		Reusable parts
Bridge edge beam anchor 15.0	Nailing cone 15.0	Screw-in cone 15.0
E		

Subsequently drilled suspension point with Suspension cone 15.0 with collar

Lost parts		Reusable parts	
Rock anchor spreader unit 15.0	Tie rod 15.0	Rock anchor installation tube	Suspension cone 15.0 with collar
	Construction of the second sec	0	

Assembly

Assembling platform

The modular design of the working platform assembled from system components means that many different combinations are possible.

Depending on the project, the actual design may differ significantly from that described here.



NOTICE

- There must be a flat, firm base capable of supporting the load.
- Prepare a sufficiently large assembly area.
- Tightening torque of the bracing tube couplers: 50 Nm
- During all assembly and dismantling work on the working platform that is carried out on the structure itself, the operators must use fall-arrest equipment (e.g. safety harness).

Example: Decking above waling

► Follow the shop drawing / assembly plan.

Mounting the decking supports

- Prepare squared timbers to place the multi-purpose walings onto (height: min. 120 mm).
- Lay down multi-purpose walings, spaced apart by the exact centre-to-centre distance.

The connection plates must be facing upwards.



- a ... centre-to-centre distance
- x = y ... diagonals
- A Multi-purpose waling

Secure Doka beams H20 to the multi-purpose walings

using Beam screws S 8/70 or Flange clamps H20.





- B Doka beam H20
- C Beam screw S8/70
- D Flange clamp H20
- Beam screw S 8/70: Width-across 13 mm Hole diameter: 10 mm
- Flange clamp H20: Width-across 19 mm

Mounting the deck-boards



The cut-outs in the platform decking may vary, depending on the project!

Fasten deck-boards to the Doka beams with Torx TG 6x90 A2 universal countersunk screws.

۲

Assembly

The deck-boards must be fastened to every formwork beam by 2 screws! Do a sight-check to make sure that the deckboards have been fixed properly!



Cut-out needed in platform decking:



a ... 170 mm

- b ... 150 mm
- c ... 270 mm
- d ... 50 mm
- A Multi-purpose waling

E Plank 5/20 cm

Installing crane hoisting points

Drill the holes for the Lifting rod 15.0 in the deckboards.

Diameter of drilled hole: min. 20mm

Mount the Lifting rod 15.0 and Retaining plate 15.0.





- F Lifting rod 15.0
- G Retaining plate 15.0



i

To avoid trip hazards, the Lifting rod 15.0 with Retaining plate 15.0 can be installed in the outermost Doka beam H20.

Follow the directions in the 'Lifting rod 15.0' Operating Instructions!

Mounting the railing



Follow the directions in the 'Edge protection system XP' User Information booklet.

> Pin the Insertion adapter XP onto the multi-purpose walings with 2 Connecting pins 10cm and secure these with Spring cotters 5mm.



H Insertion adapter XP

- I Connecting pin 10cm + Spring cotter 5mm
- > Working from below, push the Toeboard holder XP 0.60m onto the Handrail post XP 1.20m (not needed when using the Protective grating XP).

(I)

98133-205-04

> Push a Handrail post XP 1.20m onto the Insertion adapter until it locks ('Easy-Click' function).



- H Insertion adapter XP
- J Handrail post XP 1.20m
- K Toeboard holder XP 1.20m
 - The locking mechanism must engage. The bracket of the toeboard holder must be pointing downward, facing the platform.

Mounting the guard-rail boards

Insert and secure the guardrail boards.



- K Toeboard holder XP 1.20m
- L Guardrail board
- M Toeboard

User Information Platforms assembled from system components

Pre-assembling the vertical unit

- Prepare squared timbers to place the multi-purpose walings onto (height: min. 120 mm).
- Lay down multi-purpose walings, spaced apart by the exact centre-to-centre distance.

The connection plates must be facing upwards.



a ... centre-to-centre distance

x = y ... diagonals

- A Multi-purpose waling
- Brace the multi-purpose walings in the horizontal and the diagonal. width across flats 22 mm



- B Screw-on coupler 48mm 50
- C Scaffold tube 48.3mm (horizontal)
- D Swivel coupler 48mm
- E Scaffold tube 48.3mm (diagonal)

Distance between swivel coupler and screw-on coupler: max. 160 mm.

Bolt the Universal suspension head into the multipurpose walings with 2 Connecting pins 10cm and secure these with Spring cotters 5mm.



- **F** Universal suspension head
- G Connecting pin 10cm + Spring cotter 5mm

Use square bolts to secure squared timber 8x16 cm to the vertical multi-purpose walings.



H Squared timber 8x16 cm

Threaded-fastener material required for each multi-purpose waling:

- I square bolt M10x180
- 1 washer 10
- 1 hexagon nut M10



Instead of the squared timber, Facade precast member clamps V can be bolted to the multipurpose walings.



I Facade precast member clamp V

- Set down the platform on a temporary support.
- Pin Spindle struts T7 onto the multi-purpose walings with Connecting pins 10cm and secure these with Spring cotters 5mm.
- Adjust the Spindle struts T7 to the length shown in the shop drawing / assembly plan.



- A Platform
- B Spindle strut T7
- **C** Connecting pin 10cm + Spring cotter 5mm
- > Attach the lifting chains to the red safety bows.



- **D** Safety bow (red)
- E Universal suspension head
- > Lift the vertical unit into position on the platform.

- Pin the Universal suspension heads to the multi-purpose walings of the platform with Connecting pins 10cm and secure the connecting pins with Spring cotters 5mm.
- Swing the Spindle struts T7 forward and pin them to the multi-purpose walings of the vertical unit with Connecting pins 10cm and secure the connecting pins with Spring cotters 5mm.



- A Platform
- B Spindle strut T7
- **C** Connecting pin 10cm + Spring cotter 5mm
- D Safety bow
- E Universal suspension head
- F Vertical unit

Assembly

Repositioning

NOTICE

Moving the platform

Notes on safe repositioning

!

During the planning phase, consideration should also be given to the repositioning order and the removal of the last platform!

- Passenger transportation' is forbidden!
- Use tag ropes for safe guidance throughout the entire repositioning operation.
- In general, the last platform is where there are access and exit routes for the regular work sequence. Vertical access is usually provided by stair towers or aerial work platforms.
- If there are window or door openings in the façade, then access can also be enabled through these façade openings.



- A Starting and finishing point
- B Stair tower or aerial work platforms
- C Façade opening
- D Folding platform K

NOTICE

 Local regulations, or the result of a hazard assessment carried out by the erector, may necessitate the use of personal fall-arrest systems (e.g. safety harnesses) during repositioning.



 When one platform is repositioned, this leaves exposed fall-hazard locations on the remaining units. Each of these openings has to be closed off with a side railing or a barrier set up at least 2.0 m short of the drop-off edge (see 'Sideguards on exposed platform-ends').



• The personnel in charge of the repositioning operation are responsible for positioning the access prohibition barriers correctly.



The FreeFalcon mobile fall protection mast permits a secure attachment point to be created for the safety harness.



User instruction prior to use of the FreeFalcon is mandatory.

Follow the directions in the 'FreeFalcon' Operating Instructions. The platforms are normally lifted using suitable fourpart lifting chains such as the Doka 4-part chain 3.20m. Use the Transport fork 1.3t adjustable if the platform cannot be disengaged and lifted clear with a four-part lifting chain.



Working from the second-last platform, disengage the anti-liftout guard of the last platform. The red lifting bow (A) must be shifted into the stand-by position (fixed in the short slot).



Re-lock the anti-liftout guard. After hanging the platform into place, move the lifting bow back into the locked position (fixed in the long slot so that the lifting bow is flush with the platform decking).

Transport fork 1.3t adjustable

- Adjustable fork width and fork length
- Integrated tag-lines
- Three attachment possibilities for 2-part lifting chains for optimum (horizontal) transport of the platforms
- Attaching/detaching the 2-part lifting chain is easy in the parking position (bracket tilts down when lowered to the ground



b ... 90, 137, 204 or 227 cm l ... 275, 324, 373 or 422 cm h ... 385 cm

Max. carrying capacity: 1300 kg (2870 lbs)

ÍÌ

Follow the directions in the 'Transport fork 1.3t adjustable' Operating Instructions.



Unlock the anti-liftout guard. Before the platform can be lifted off its suspension points, the red lifting bow (A) must be shifted into the stand-by position (fixed in the short slot).





Starting up

Hanging the platform into place

- Remove any loose items from the platforms, or secure them firmly.
- Passenger transportation' is forbidden!

The platforms are normally lifted using suitable fourpart lifting chains such as the Doka 4-part chain 3.20m.



Follow the directions in the 'Doka 4-part chain 3.20m' Operating Instructions!

 Attach a four-part lifting chain to the front and rear crane hoisting points.
 Spread angle β: max. 30°



Use a four-part lifting chain to lift the platform and, using tag-lines, guide it to the place of use.



A Safety bow (red)

- **B** Lifting rod 15.0
- C Doka 4-part chain 3.20m

Hang the platform into place.



Once the platform has been hung into place on the suspension cone, the load is removed from the fourpart lifting chain.



The red safety bows drop to their initial position, automatically securing the platform against lift-out.

Secured position = safety bow (red) fully lowered in the Universal suspension head.

Dismantling



NOTICE

- There must be a flat, firm base capable of supporting the load.
- Provide a sufficiently large dismantling space.
- Remove any loose items from the platforms, or secure them firmly.
- During all assembly and dismantling work on the working platform that is carried out on the structure itself, the operators must use fall-arrest equipment (e.g. safety harness).

Disassembly with four-part lifting chain

Attach a four-part lifting chain to the front and rear crane hoisting points.





- A Safety bow (red)
- B Lifting rod 15.0
- C Doka 4-part chain 3.20m

> Lift the platform out of its suspension points.



- A Safety bow (red)
- **B** Lifting rod 15.0
- C Doka 4-part chain 3.20m
- > Place the platform on a temporary support.



From this point on disassembly takes place on the ground and is the reverse of the assembly procedure.

General

Design variants

Use with Positioning unit DokaCC



B Positioning unit DokaCC

i

C Multi-purpose waling WU12

Follow the directions in the 'Tunnel system DokaCC' User Information booklet.

Use in narrow shafts and against pit lining





- a ... 60 80 cm
- A Universal suspension head
- B Connecting pin 10cm + Spring cotter 5mm
- **C** Multi-purpose waling WS10
- **D** Adjustable waling extension FF20/50
- E Beam clamp Top50
- F Hexagon bolt ISO 4014 M20x120 8.8
 2 washers ISO 7089 20 St-200 HV,
 Hexagon nut ISO 7040 M20 self-locking 8
- ${\bf G}\,$ Barrier such as sheet wall, for example
- H Hardwood packer

Threaded-fastener material required for each adjustable waling extension:

- 2 hexagon bolts ISO 4014 M20x120 8.8
- 4 washers ISO 7089 20 St-200 HV
- 2 hexagon nuts ISO 7040 M20 self-locking 8

Use at angles of inclination

General



A Universal suspension head

B Corner plate FF20 G

WARNING

At angles of inclination $\alpha \ge 45^\circ$ the safety bow does not provide security against lift-out.

Falling hazard!

Provide security against lift-out by fitting the safety wedge into the Universal suspension head!



- A Safety wedge for universal suspension head
- B Snap link with rope
- C Spring cotter 5mm
- **D** Safety bow
- E Cone screw M30 SW50 7cm





F ... permitted shear force (lift-out force): 12 kN

Installation of safety wedge

- 1) Move the safety bow into the stand-by position (fixed in the short slot).
- Secure the snap link of the safety wedge to the Universal suspension head.
- Install the safety wedge by driving it in from right to left.
- Secure safety wedge at the end by inserting Spring cotter 5mm.

NOTICE

- In planning, allow for accessibility of the safety wedge.
- Separate static verification is required.
- Provide suitable handling equipment.
- Check the multi-purpose waling at the universal suspension head for collision.
 If necessary, use a Corner plate FF20 G.

Suspension head WS10

Imposed loads



a ... 107 mm (Multi-purpose waling WS10 and Multi-purpose waling WU12)

- A Cone screw M30 SW50 7cm
- B Universal climbing cone 15.0 2G
- C Stop anchor 15.0 (lost anchoring component)

Imposed loads with Universal climbing cone 15.0 2G

and Cone screw M30 SW50 7cm

- H ... permitted horizontal load: 60 kN
- V ... permitted vertical load: 30 kN

Note the restrictions in the section headed 'Other possible anchorages'!

NOTICE

I

Use of the suspension point is possible up to a wall angle of inclination of max. 45°!

Ways of installing the horizontal multi-purpose waling



B Formwork element connector FF20/50

- C Multi-purpose waling
- E Bracing
- F Connecting pin 10cm + Spring cotter 5mm

Practical example



- A Suspension head WS10
- **B** Formwork element connector FF20/50
- C Multi-purpose waling
- D Strut or spindle strut
- E Bracing
- F Safety bow (front crane hoisting point)
- **G** Lifting rod 15.0 and Retaining plate 15.0 (rear crane hoisting point)
- H Squared timber

Other possible anchorages

Load-bearing capacity of the steel of suitable suspension points

	V _{perm.} [kN]	H _{perm.} [kN]	
Universal climbing cone 15.0 2G + Cone screw M30 SW50 7cm	30	60	
Suspension cone 15.0 5cm	30	40	
Suspension cone 15.0 f. insulation up to 11cm + Cone screw Rd28	20	40	
Screw-in cone 15.0 + Bridge edge beam anchor 15.0	30	30	
Suspension cone 15.0 with collar	30	40	
The required cube compressive strength of the con- crete at the time of loading must be specified sepa- rately for each project by the structural designer . It will depend on the following factors:	[i	Follow the directions in the Calculation Guide entitled 'Load-bearing capacity of anchorages in concrete', and/or ask your Doka technician!
Ioad actually occurring			NOTICE
 anchoring depth h_{ef} reinforcement / extra reinforcement steel distance from edge 		·	Separate statics analysis is required for dimensioning of the suspension point.
The introduction of the forces, the transfer of these forces into the structure, and the stability of the overall construction, must all be verified by the structural designer.			

The required cube compressive strength $f_{ck,cube,current}$ must be at least 10 $N/mm^2,$ however.

Anchorage with Suspension cone 15.0 5cm

U					
Lost parts			Reusab	le parts	
Pigtail anchor 15.0	Sealing sleeve 15.0 5cm	Cantilever position- ing cone 15.0 5cm	Tie rod 15.0, length approx. 20 cm	Super plate 15.0	Suspension cone 15.0 5cm
			((())))))))))))))))))))))))))))))))))))		
or	or		c	r	~
Stop anchor 15.0	Sealing sleeve S 15.0 5cm		Fixing p	ate 15.0	
Community			(c)	

Suspension cone 15.0 f. insulation up to 11cm

Lo	st parts	Reusable parts	
Pigtail anchor 15.0	Sealing sleeve 15.0 f. insulation up to 11cm	Suspension cone 15.0 f. insulation up to 11cm	Cone screw Rd28
		Ø	
or Stop anchor 15.0		in addition, where needed: Positioning disc Rd28	
annannann			

Anchorage with Screw-in cone 15.0

Lost parts		Reusable parts
Bridge edge beam anchor 15.0	Nailing cone 15.0	Screw-in cone 15.0
	<	

Subsequently drilled suspension point with Suspension cone 15.0 with collar

Lost parts		Reusable parts	
Rock anchor spreader unit 15.0	Tie rod 15.0	Rock anchor installation tube	Suspension cone 15.0 with collar
((IHHHIIO)	(Construction of the second		

Sideguards on exposed platform-ends

On platforms that do not completely encircle the structure, suitable sideguards must be placed across exposed end-of-platform zones.

Note:

The plank and board thicknesses given here comply with the C24 category of EN 338. Observe all national regulations applying to deck-

Edge protection system XP

boards and guard-rail boards.



Follow the directions in the 'Edge protection system XP' User Information booklet.

Assembly:

- Fasten Railing clamps XP onto the decking of the working platform, by tightening the wedge (clamping range 2 to 43 cm).
- Working from below, push a Toeboard holder XP 1.20m onto the Handrail post XP 1.20m.
- Push the Handrail post XP 1.20m into the post-holding fixture on the Railing clamps XP until the locking mechanism engages.
- Insert and secure the guardrail boards.



- A Guardrail board min. 15/3 cm (site-provided)
- B Handrail post XP 1.20m
- C Railing clamp XP 40cm
- D Toeboard holder XP 1.20m
- **E** Working platform assembled from system components

Fall-arrest systems on the structure

Edge protection system XP

- Attached with Screw-on shoe XP, railing clamp, Handrail-post shoe or Step bracket XP
- Protective grating XP, guardrail boards or scaffold tubes can be used as the safety barrier



a ... > 1.00 m

\sim	\sim
	•
-	

Handrail clamp S

- Attached with integral clamp
- Guard-rail boards or scaffold tubes can be used as the safety barrier

system XP' User Information booklet!

Follow the directions in the 'Edge protection



a ... > 1.00 m



Follow the directions in the "Handrail clamp S" User information!

Handrail post 1.10m

- Fixed in a Screw sleeve 20.0 or Attachable sleeve 24mm
- Guard-rail boards or scaffold tubes can be used as the safety barrier



a ... > 1.00 m

i

Follow the directions in the 'Handrail post 1.10m' User Information!

Transporting, stacking and storing

Utilise the benefits of Doka multi-trip packaging on your site.

Multi-trip packaging such as containers, stacking pallets and skeleton transport boxes keep everything in place on the site, minimise time wasted searching for parts, and streamline the storage and transport of system components, small items and accessories.

Doka skeleton transport box 1.70x0.80m

Storage and transport device for small items



Max. load-bearing capacity: 700 kg (1540 lbs) Permitted imposed load: 3150 kg (6950 lbs)

To make the Doka skeleton transport box easier to load and unload, one of its sidewalls can be opened.

Using Doka skeleton transport boxes 1.70x0.80m as storage units

Max. n° of units on top of one another

Outdoors (on the site)	Indoors
Floor gradients up to 3%	Floor gradients up to 1%
2	5
It is not allowed to stack empty pallets on top of one another!	

NOTICE

Stacked multi-trip boxes or pallets must have the heaviest boxes at the bottom and the lightest at the top.

Using Doka skeleton transport boxes 1.70x0.80m as transport devices

Lifting by crane

NOTICE

- Multi-trip packaging items may only be lifted one at a time.
- Only lift the boxes when their sidewalls are closed!
- Use a suitable crane suspension tackle (e.g. Doka 4-part chain 3.20m).
 Do not exceed the permitted load-bearing capacity.
- Spread angle β max. 30°!



9234-203-01

Repositioning by forklift truck or pallet stacking truck

The forks can be inserted under either the broadside or the narrowside of the containers.

Doka multi-trip transport box

Storage and transport device for small items

Doka multi-trip transport box 1.20x0.80m



Max. carrying capacity: 1500 kg (3300 lbs) Permitted imposed load: 7850 kg (17300 lbs)

Different items in the Doka multi-trip transport box can be kept separate with the **Multi-trip transport box par-titions 1.20m or 0.80m**.



A Slide-bolt for fixing the partition

Possible ways of dividing the box



Doka multi-trip transport box 1.20x0.80mx0.41m



Max. carrying capacity: 750 kg (1650 lbs) Permitted imposed load: 7200 kg (15870 lbs)

Using Doka multi-trip transport boxes as storage units

Max. n° of units on top of one another

Outdoors (on the site)		In	doors
Floor gradients up to 3%		Floor grad	lients up to 1%
Doka multi-	trip transport box	Doka multi-	trip transport box
1.20x0.80m	1.20x0.80x0.41m	1.20x0.80m	1.20x0.80x0.41m
3	5	6	10
It is not allow pallets on to	ed to stack empty p of one another!		

NOTICE

Stacked multi-trip boxes or pallets must have the heaviest boxes at the bottom and the lightest at the top.

Using Doka multi-trip transport boxes as transport devices

Lifting by crane

NOTICE

- Multi-trip packaging items must be lifted individually.
- Use a suitable crane lifting tackle (e.g. Doka 4-part chain 3.20m).
 Do not exceed the permitted load-bearing capacity.
- Spread angle β max. 30°!



Repositioning by forklift truck or pallet stacking truck

The forks can be inserted under either the broadside or the narrowside of the containers.

Doka stacking pallet 1.55x0.85m and 1.20x0.80m

Storage and transport devices for long items.



Max. carrying capacity: 1100 kg (2420 lbs) Permitted imposed load: 5900 kg (12980 lbs)

Using Doka stacking pallets as storage units

Max. n° of units on top of one another

Outdoors (on the site)	Indoors
Floor gradients up to 3%	Floor gradients up to 1%
2	6
It is not allowed to stack empty pallets on top of one another!	

NOTICE

1

- Stacked multi-trip boxes or pallets must have the heaviest boxes at the bottom and the lightest at the top.
- How to use with Bolt-on castor set B:
 - Always apply the fixing brake when the container is 'parked'.
 - When Doka stacking pallets are stacked, the bottom pallet must NOT be one with a bolt-on castor set mounted to it.

Using Doka stacking pallets as transport devices

Lifting by crane

ļ

NOTICE

- Multi-trip packaging items may only be lifted one at a time.
- Use a suitable crane suspension tackle (e.g. Doka 4-part chain 3.20m).
 Do not exceed the permitted load-bearing capacity.
- Load the items centrically.
- Fasten the load to the stacking pallet so that it cannot slide or tip out.
- Spread angle β max. 30°!



Repositioning by forklift truck or pallet stacking truck

NOTICE

ļ

- Load the items centrically.
- Fasten the load to the stacking pallet so that it cannot slide or tip out.

Doka accessory box

Storage and transport device for small items



Max. carrying capacity: 1000 kg (2200 lbs) Permitted imposed load: 5530 kg (12191 lbs)

Doka accessory boxes as storage units

Max. n° of units on top of one another



NOTICE

- Stacked multi-trip boxes or pallets must have the heaviest boxes at the bottom and the lightest at the top.
- How to use with Bolt-on castor set B:
 - Always apply the fixing brake when the container is 'parked'.
 - When Doka stacking pallets are stacked, the bottom pallet must NOT be one with a bolt-on caster set mounted to it.

Doka accessory box as transport devices

Lifting by crane

NOTICE

- Multi-trip packaging items must be lifted individually.
- Use a suitable crane lifting tackle (e.g. Doka 4-part chain 3.20m).
 Do not exceed the permitted load-bearing capacity.
- Spread angle β max. 30°!



Repositioning by forklift truck or pallet stacking truck

The forks can be inserted under either the broadside or the narrowside of the containers.

Bolt-on castor set B

The Bolt-on caster set B turns the stacking pallet into a fast and manoeuvrable transport device. Suitable for drive-through access openings > 90 cm.



The Bolt-on caster set B can be mounted to the following multi-trip packaging items:

- Doka accessory box
- Doka stacking pallets
- Protective barrier Z pallet



Follow the directions in the 'Bolt-on castor set B' Operating Instructions!

	[kg]	Article N°		[kg]	Article N°
Universal suspension head Universal-Aufhängekopf Galvanised Length: 36.5 Width: 16 cn Height: 32.1	14.0 ; cm n cm	580408000	Top100 tec waling WU14 0.50m Top100 tec waling WU14 0.75m Top100 tec waling WU14 1.00m Top100 tec waling WU14 1.25m Top100 tec waling WU14 1.50m Top100 tec waling WU14 2.00m Top100 tec waling WU14 2.25m Top100 tec waling WU14 2.50m	15.2 21.4 28.6 38.3 43.3 51.2 57.8 67.8 72.2	586901000 586902000 586903000 586905000 586905000 586907000 586908000 586908000 586909000
Safety wedge for universal suspension Sicherungskeil Universal-Aufhängekopf Galvanised Length: 30 c	n head 0.70	580409000	Top100 tec waling WU14 2.75m Top100 tec waling WU14 3.00m Top100 tec waling WU14 3.50m Top100 tec waling WU14 4.00m Top100 tec waling WU14 4.50m Top100 tec waling WU14 5.00m Top100 tec waling WU14 6.00m Top100 tec-Riegel WU14 Painted blue	79.0 85.8 100.7 114.2 136.5 144.5 166.5 182.2	586910000 586911000 586912000 586913000 586914000 586915000 586916000 586917000
Suspension head WS10 Aufhängekopf WS10 Galvanised Length: 21 c Width: 18 cn Height: 23 cl	8.1 m m	580449000			
Multi-purpose waling WS10 Top50 0.50 Multi-purpose waling WS10 Top50 0.75 Multi-purpose waling WS10 Top50 1.25 Multi-purpose waling WS10 Top50 1.25 Multi-purpose waling WS10 Top50 1.50 Multi-purpose waling WS10 Top50 2.00 Multi-purpose waling WS10 Top50 2.25 Multi-purpose waling WS10 Top50 2.75 Multi-purpose waling WS10 Top50 2.75 Multi-purpose waling WS10 Top50 3.00 Multi-purpose waling WS10 Top50 3.00 Multi-purpose waling WS10 Top50 3.00 Multi-purpose waling WS10 Top50 3.00 Multi-purpose waling WS10 Top50 3.00	Dm 10.2 5m 14.9 Jm 19.6 5m 24.7 Jm 29.7 5m 35.0 Jm 38.9 5m 44.2 Dm 48.7 5m 54.2 Dm 60.2 Dm 68.4	580001000 580002000 580004000 580005000 580005000 580007000 580008000 580009000 580010000 580010000 580012000	UniKit channel UK12 1.12m UniKit channel UK12 1.62m UniKit channel UK12 2.62m Profil UK12 Painted blue	14.1 20.6 27.0 32.8	582960000 582962000 582960000 582961000
Multi-purpose waling WS10 Top50 4.50 Multi-purpose waling WS10 Top50 4.50 Multi-purpose waling WS10 Top50 5.00 Multi-purpose waling WS10 Top50 5.50 Multi-purpose waling WS10 Top50 6.00 Mehrzweckriegel WS10 Top50	0m 79.4 0m 89.1 0m 102.0 0m 112.4 0m 118.0	580013000 580014000 580015000 580016000 580017000	Facade precast member clamp V Fassaden-Fertigteilklemme V Galvanised Length: 70 cm Height: 41 cm	8.1	580694000
Painted blue			Width-across: 50 m	nm	
Painted blue Multi-purpose waling WU12 Top50 1.00 Multi-purpose waling WU12 Top50 1.25	0m 25.3 5m 32.0	580018000 580019000	Width-across: 50 m Formwork element connector FF20/50 Z Elementverbinder FF20/50 Z Painted blue Length: 55 cm	nm 6.0	587533000
Multi-purpose waling WU12 Top50 1.00 Multi-purpose waling WU12 Top50 1.20 Multi-purpose waling WU12 Top50 1.25 Multi-purpose waling WU12 Top50 1.55 Multi-purpose waling WU12 Top50 2.00 Multi-purpose waling WU12 Top50 2.00 Multi-purpose waling WU12 Top50 3.00 Multi-purpose waling WU12 Top50 4.00 Mehrzweckriegel WU12 Top50	0m 25.3 5m 32.0 0m 37.5 5m 44.2 0m 50.0 0m 63.1 0m 75.7 0m 90.7 0m 103.4	580018000 580019000 580020000 580022000 580023000 580023000 580024000 580025000 580026000	Width-across: 50 m Formwork element connector FF20/50 Z Elementverbinder FF20/50 Z Painted blue Length: 55 cm Ausgleichslasche FF20/50 Ausgleichslasche FF20/50 Painted blue Length: 87 cm	nm 6.0 9.1	587533000
Painted blue Multi-purpose waling WU12 Top50 1.00 Multi-purpose waling WU12 Top50 1.20 Multi-purpose waling WU12 Top50 1.72 Multi-purpose waling WU12 Top50 2.00 Multi-purpose waling WU12 Top50 2.00 Multi-purpose waling WU12 Top50 3.00 Multi-purpose waling WU12 Top50 3.00 Multi-purpose waling WU12 Top50 3.00 Multi-purpose waling WU12 Top50 4.00 Mehrzweckriegel WU12 Top50 Painted blue	0m 25.3 5m 32.0 0m 37.5 5m 44.2 0m 50.0 0m 63.1 0m 75.7 0m 90.7 0m 103.4	580018000 580020000 580021000 580022000 580022000 580024000 580025000 580026000	Width-across: 50 m Formwork element connector FF20/50 Z Elementverbinder FF20/50 Z Painted blue Length: 55 cm Adjustable waling extension FF20/50 Ausgleichslasche FF20/50 Painted blue Length: 87 cm Beam clamp Top50 Trägerklammer Top50 Painted blue Height: 15 cm	nm 6.0 9.1 1.2	587533000 587532000 580081000

	[kg]	Article N°		[kg]	Article N°
Spindle strut T7 75/110cm Spindle strut T7 100/150cm Spindle strut T7 150/200cm Spindle strut T7 200/250cm Spindle strut T7 305/355cm Spindel strut T7 305/355cm Spindelstrebe T7	13.2 16.8 21.6 26.2 29.4 35.0 Galvanised	584308000 584309000 584324000 584325000 584326000 584327000	Doka beam H20 eco N 1.80m Doka beam H20 eco N 2.45m Doka beam H20 eco N 2.65m Doka beam H20 eco N 2.90m Doka beam H20 eco N 3.30m Doka beam H20 eco N 3.60m Doka beam H20 eco N 3.90m Doka beam H20 eco N 4.50m Doka beam H20 eco N 4.90m Doka beam H20 eco N 5.90m Doka beam H20 eco Nm Doka beam H20 eco Nm Doka beam H20 eco Nm SDoka-Träger H20 eco N	8.5 11.5 12.5 13.6 15.5 16.9 18.3 21.2 23.0 27.7 4.7 4.7	189283000 189271000 189272000 189284000 189286000 189286000 189286000 189287000 189287000 189299000 189289000
Connecting pin 10cm Verbindungsbolzen 10cm	0.34 Galvanised Length: 14 cm	580201000	Doka beam H20 top P 1.80m Doka beam H20 top P 2.45m Doka beam H20 top P 2.65m Doka beam H20 top P 2.90m Doka beam H20 top P 3.30m Doka beam H20 top P 3.60m Doka beam H20 top P 3.90m Doka beam H20 top P 4.50m	9.5 13.0 14.1 15.4 17.5 19.1 20.7 23.9	189701000 189702000 189703000 189704000 189705000 189706000 189707000 189707000 189708000
Spring cotter 5mm Federvorstecker 5mm	0.03 Galvanised Length: 13 cm	580204000	Doka beam H20 top P 4.90m Doka beam H20 top P 5.90m Doka beam H20 top Pm Doka beam H20 top Pm BS Doka-Träger H20 top P Varnished yellow	26.0 31.3 5.3 5.3	189709000 189710000 189700000 189711000
Doka beam H20 eco P 1.80 Doka beam H20 eco P 2.45 Doka beam H20 eco P 2.65 Doka beam H20 eco P 2.90 Doka beam H20 eco P 3.30 Doka beam H20 eco P 3.60 Doka beam H20 eco P 4.50 Doka beam H20 eco P 4.50 Doka beam H20 eco P 4.90 Doka beam H20 eco P 4.90	m 9.5 m 13.0 m 14.1 m 15.4 m 15.4 m 19.1 m 20.7 m 23.9 m 26.0 m 31.3	189940000 189936000 189937000 189930000 189941000 189942000 189943000 189943000 189932000 189955000			
Doka beam H20 eco P 9.00 Doka beam H20 eco Pm Doka beam H20 eco Pm Doka-Träger H20 eco P	1 47.7 5.3 BS 5.3 Varnished yellow	7 189956000 3 18999000 3 189957000	Doka beam H20 top N 1.80m Doka beam H20 top N 2.45m Doka beam H20 top N 2.65m Doka beam H20 top N 2.90m Doka beam H20 top N 3.30m Doka beam H20 top N 3.60m Doka beam H20 top N 4.50m Doka beam H20 top N 4.50m Doka beam H20 top N 4.90m Doka beam H20 top N 5.90m Doka beam H20 top N 5.90m Doka beam H20 top Nm Doka beam H20 top Nm Doka beam H20 top Nm SDoka-Träger H20 top N	8.5 11.5 12.5 13.6 15.5 16.9 18.3 21.2 23.0 27.7 4.7 4.7	189011000 189012000 189013000 189015000 189015000 189016000 189019000 189019000 189020000 189020000
			Beam screw S 8/70 Riegelverschraubung S 8/70 Galvanised Length: 8 cm Width-across: 13 mm	0.06	580116500





	[kg]	Article N°		[kg]	Article N°
Transport fork 1.3t adjustable 731.0 Umsetzgabel 1,3t verstellbar 0		586234000	Additional tools MF Zusatzwerkzeuge MF	5.4	580682000
	Calvarised Delivery condition: folded closed Follow the directions in the "Opera- ting Instructions"!		(A) Reversible ratchet 3/4" Galvanised	1.5	580894000
			(C) Box nut 17 1/2" (D) Box nut 16 1/2"	0.81 0.07 0.08	580685000 580640000
		CE	(E) Extension 20cm 3/4" (F) Transition piece A 1/2"x3/4" (G) Universal cone spanner 15 0/20 (0.68 0.18 0.090	580683000 580684000 581448000
			Galvanised Width-across: 50 mm		504 420000
A CONTRACTOR			(H) Satety Ruler SK Length: 18 cm (I) Hexagon bit socket 14mm 1/2"	0.02	581439000 581583000
Lifting set Xclimb 60 Anschlagset Xclimb 60	1.2	581387000			
	Galvanised Follow the directions in the "Opera- ting Instructions"!	CE			
Doka 4-part chain 3.20m Doka-Vierstrangkette 3,20m	15.0	588620000			
R	Follow the directions in the "Opera- ting Instructions"!		Tie rod system 15.0		
		66	Universal climbing cone 15.0 2G	1.3	581977500
			Galvanise Orange	d	
			Length: 12 Diameter:	2.8 cm 5.3 cm	
Tool box GF GF-Werkzeugbox	7.2	580390000	Universal climbing cone 15.0	1.3	581977000
included in scope of supply: (A) Reversible ratchet 1/2 "	0.73	580580000	Universal-Kletterkonus 15,0 Galvanise	d	
(B) Ring spanner 13/15 (C) Ring spanner 16/18 (D) Ring spanner 17/19 (E) Combination wrench 36	0.25 0.23 0.27 0.27	580599000 580644000 580590000 582860000	Orange Length: 12 Diameter:	2.8 cm 5.3 cm	
(F) Fork wrench 30/32 (G) Fork wrench 22/24	0.73 0.80 0.22	580897000 580587000	Sealing sleeve K 15.0	0.03	581976000
 (H) Fork wrench 13/17 (I) Extension 22cm 1/2" (J) Extension 11cm 1/2" 	0.08 0.31 0.20	580577000 580582000 580581000	Orange Length: 12	2 cm	
 (K) Universal joint coupling (L) Box nut 30 1/2" (M) Box nut 24 1/2" (N) Box nut 19 1/2" I 	1/2" 0.16 0.20 0.12 0.16	580583000 580575000 580584000 580598000	Diameter:	6 cm	
(O) Box nut 18 1/2" L (P) Box nut 15 1/2"	0.15	580642000 580676000	Concrete cone 52mm Betonkonus 52mm	0.19	581939000
	0.06	560576000	Grey		
			Fair-faced concrete positioning cone	MF 15.0 1.5	581928000
			Galvanise Length: 12 Diameter:	d 2.6 cm 5.3 cm	
19999			Sealing disc 30/53	0.003	581838000
and the second			Dichtscheibe 30/53 Black		
Contraction of the second seco					
\checkmark					

	[k	g]	Article N°			[kg]	Article N°
Fair-faced concrete plug 52 Sichtbetonstopfen 52mm Kunstst	mm plastic 0.	.01	581850000	Wall anchor 15.0 15cm Wandanker 15,0 15cm	Columniand	1.5	581893000
	Grey				Gaivaniseu		
Cone screw M30 SW50 7cm 0.88 Konusschraube M30 SW50 7cm 0.88		581444500	\checkmark				
())	Green Length: 10 cm Diameter: 7 cm Width-across: 50 mm			Multi-trip packaging Doka skeleton transport bo Doka-Gitterbox 1,70x0,80m	ox 1.70x0.80m	87.0	583012000
Cone screw B 7cm Konusschraube B 7cm	0.	.86	581444000		Galvanised Height: 113 cm		
	Red Length: 10 cm Diameter: 7 cm Width-across: 50 mm						
Form-ply protector 32mm Schalhautschutz 32mm	0. Galvanised Width-across: 70 mm	.38	580220000				
				Doka multi-trip transport be Doka-Mehrwegcontainer 1,20x0,	ox 1.20x0.80m ^{80m} Galvanised Height: 78 cm	70.0	583011000
Positioning clamp M30 Vorlaufklemme M30	0. Galvanised Diameter: 4 cm	.19	581833000				
Positioning disc M30 Vorlaufscheibe M30	0.	.25	581975000				
	Galvanised Diameter: 9 cm			Multi-trip transport box par Multi-trip transport box par Mehrwegcontainer Unterteilung	tition 0.80m tition 1.20m	3.7 5.5	583018000 583017000
Stop anchor 15.0 B11 Sperranker 15,0 B11	0. Non-treated	.55	581868000	0	Timber parts galvanised		
Stop anchor 15.0 A16	0.	.38	581997000	Doka multi-trip transport be Doka-Mehrwegcontainer 1,20x0,	bx 1.20x0.80x0.41m B0x0,41m	42.5	583009000
C parameters	Non-treated				Gaivaniseu		
Stop anchor 15.0 A21 Sperranker 15,0 A21	0.	.44	581884000				
E January and and a start of the start of th	Non-treated			Doka stacking pallet 1.55x0 Doka-Stapelpalette 1,55x0,85m).85m Galvanised Height: 77 cm	41.0	586151000
Stop anchor double-ended Sperranker beidseitig 15,0 K20	15.0 K20 0.	.76	581820000				
and a strange	Non-treated Custom lengths can be ordered under the special-component Art 580100000, quoting the designat and the desired length in mm.	n° tion					

[kg] Article N°





Near to you, worldwide

Doka is one of the world leaders in developing, manufacturing and distributing formwork technology for use in all fields of the construction sector.

With more than 160 sales and logistics facilities in over 70 countries, the Doka Group has a highly efficient distribution network which ensures that equipment and

technical support are provided swiftly and professionally.

An enterprise forming part of the Umdasch Group, the Doka Group employs a worldwide workforce of more than 6000.

